FIVE ROUND LOADING AND MARK I RUGER

- To make a five round loader, modify the rear half of the loader as shown. Cut at 1 1/4" and 2 7/8" Reassemble the loader and drill two new 1/8" holes (the same as original) to remount the section with the adjusting screw as pictured below. (It can be moved back to the original position later to load 10 rounds.)
- For the MARK I nine shot magazine with the button on the left side, saw at 1 1/4" and at 1 5/8" to remove only 3/8" of material. Drill and remount the adjusting screw section just like the 5 round loader above.



If you have a MARK I nine shot magazine with the follower button on the right side,
YOU DO NOT HAVE TO DISASSEMBLE THE LOADER AND DO THE ABOVE MODIFICATION.

Just carefully deepen this notch a little at a time until your magazine is fully inserted, depressing the ball inside the Cliploader to release the bullets. If a 10th round is being released and falls out when you remove your magazine, deepen the notch slightly more. The 9th round should <u>just</u> slide under the feed lips of your magazine.