


Even though they're all factory magazines some dies bend the feed lips a little different than others, some magazines take a little modification to work with the Ultimate Cliploader, but does not affect the gun cycle.



This is the area that may need bowed out about the thickness of the metal lip.

The lip that hits the Ball Bearing.



Watch the ball bearing as you are pushing your magazine in to be sure the lip is moving the ball.